







Scan for Installation Manual




THREAD CONNECTOR

If your gas pressure reducer is equipped with thread connector screw it on using HEX spanner wrench included to the product turning it clockwise.




BARB CONNECTOR

If your gas pressure reducer is equipped with hose barb connector. Cut off the end of the gas hose with screw ending.




Move the clamp into the stub and assemble the pressure reducer. Make sure the clamp will not be further than 10mm from reducer.



Tighten the clamp by turning it clockwise.

WARNING! In the event of visible damage on the clamp, replace it for a new one.



Warning. To make it easier to apply the gas hose to the regulator outlet, you can heat the 2 cm hose end under warm water.